












ULTRA KÖŞE ÜÇLÜ MONTAJ TALİMATI

ULTRA KÖŞE SOFA ASSEMBLY INSTRUCTIONS

- | | | | |
|----|---|--|-----------------------|
| 1 |  | KILIT GEÇME
LUCK SWITCH | 2...Ad.
2...Pcs. |
| 2 |  | M6x20 YHB BOLT
M6x20 YHB CIVATA | 4...Pcs
4...Ad. |
| 3 |  | Saplaması M8x100
M8x100 Stud | 4 Adet
4 Pieces |
| 4 |  | M8 FLUKE NUT
KELEBEK SOMUN | 6..Pcs.
6...Ad. |
| 5 |  | G SAC SOL
G SHEET LEFT | 1..Ad.
1...Pcs. |
| 6 |  | G SAC SAG
G SHEET RIGHT | 1..Ad.
1...Pcs. |
| 7 |  | M6x40 YKB BOLT
M6x40 YKB CIVATA | 4...Pcs
4...Ad. |
| 8 |  | Saplaması M8x20
M8x20 Stud | 2 Adet
2 Pieces |
| 9 |  | M6x50 İMBUS BOLT
M6x50 İMBUS CIVATA | 2...Pcs
2...Ad. |
| 10 |  | GİZLİ AYAK
HIDDEN FOOT | 2...Ad.
2...Pcs. |
| 11 |  | PLASTİK AYAK
PLASTIC FEET | 4....Ad.
4..Pieces |

