## CabinetBed™ INC. Your Space Saving Sleep Solution™

Deluxe Series

**Assembly Instructions** 



1) Place the drawer pedalstal onto a flat surface. Use adjustable levelers on both sides and ensure even level.



2) Place Cabinet on top of the drawer pedalstal. Line up predrilled holes and use allan key (provided) to screw in bolts. There are 3 per side.



3) Pull out the bottom drawer until its fully extended,



4) Lock the drawer in place by unfolding the drawer and deck support (felt side up). The drawer will NOT be able to close when done correctly. Filp up the Lid, Then undo the barrel bolt on each side and slowly lower the front panel until it rests on the drawer box.



5) Push Tap in on center locking mechanism and unfold deck support 90 degrees until until you hear a clicking sound.



6) Unfold deck supports on both sides 90 degrees until until you hear a clicking sound. When closing bed, To lock, click button



7) Unfold deck all the way until the deck is touching the ground.



8) Pull out mattress fully as shown above. To fold up, reverse steps 3-8.