

**Coach Frame Reassembly Instructions**

**Step 7: Attach Seat Deck Slats**

**Parts Needed:**

Seat Deck

Seat Deck Slats – Quantity 12 - Full Size, Quantity 13 - Queen Size

Bolts 30mm – Quantity 24 - Full Size, Quantity 26 - Queen Size

Long Allen Key (4mm)

Put a 30mm bolt through the counter sunk holes at the end of each slat and into the predrilled holes on the seat deck support board. Please start at the center and work your way out.

You can use a power drive with the clutch set on low to snug up the bolts after you hand start them.

Finish tightening by hand only.

