

ULTRA KÖŞE MONTAJ TALİMATI ULTRA KÖŞE ASSEMBLY INSTRUCTIONS

1 AYAK BAĞLAMA ARAÇI 4...Ad. PLASTIC FEET 4...Piece	11 Sapınma M6x20 M6x20 Stud 4...Adet 4...Pieces
2 PLASTİK AYAK 4...Ad. PLASTIC FEET 4...Piece	12 M8 FLÜKE MUT KELEBEK-SÖMÜN 10...Pes. 10...Ad.
3 M6x35 YKB BOLT 8...Pes. M6x35 YKB CIVATA 8...Ad.	13 M8x60 İMBUS BOLT 2...Pes. M8x60 İMBUS CIVATA 2...Ad.
4 KILIT GEÇME 2...Ad. LATCH SWITCH 2...Pes.	14 GİZLİ AYAK 2...Ad. HIDDEN FOOT 2...Pes.
5 M6x20 YKB BOLT 4...Pes. M6x20 YKB CIVATA 4...Ad.	15 PLASTİK AYAK 4...Ad. PLASTIC FEET 4...Pieces
6 Sapınma M8x120 M8x120 Stud 2...Adet 2...Pieces	16 M8x40 YKB BOLT 8...Pes. M8x40 YKB CIVATA 8...Ad.
7 G SAG SOL 1...Ad. G SHEET LEFT 1...Pes.	17 GİZLİ AYAK 55mm 2...Ad. HIDDEN FOOT 55mm 2...Pes.
8 G SAG SAG 1...Ad. G SHEET RIGHT 1...Pes.	18 GİZLİ AYAK 50mm 1...Ad. HIDDEN FOOT 50mm 1...Pes.
9 M6x25 YKB BOLT 4...Pes. M6x20 YKB CIVATA 4...Ad.	19 PROFİL 48mm 2...Ad. PROFILE 48mm 2...Pes.
10 Sapınma M8x100 M8x100 Stud 2...Adet 2...Pieces	

