


# MOE'S

h o m e c o l l e c t i o n

## ASSEMBLY INSTRUCTIONS.

SAKURAI DINING TABLE


**BC-1081-24**



THANK YOU FOR YOUR PURCHASE!


## PART LIST

A



Top Table = 1pc


B



Leg = 2pcs

## HARDWARE LIST

1. Bolt




M8 x 40mm 16pcs

2. Spring washer



M8.5 x 13mm 16pcs

3. Flat washer



M8.5 x 18mm 16pcs

4. Allen key



1 pc

## NOTES.

Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping.

## CAUTION:

The item is heavy, assembly should be performed by two people.

