


# **ASSEMBLY INSTRUCTIONS.**

SIERRA DINING TABLE FR-1017-23



THANK YOU FOR YOUR PURCHASE!

## PARTS AND HARDWARE.

#### **PARTS LIST**

NO.	DESCRIPTION	IMAGE	Q'TY
Р1	TABLE TOP		1
P2	LEGS FRAMES	<b>\langle</b>	2
Р3	STRETCHER FRAME	+	1


#### HARDWARE LIST

NO.	DESCRIPTION	IMAGE	Q′TY
Н1	BOLT M8x40		4
H2	BOLT M8x50		8
НЗ	ALLEN KEY M4		1
H4	FLAT WASHER M8	0	12
H5	SPRING WASHER	<b>Q</b>	12

### NOTES.

Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping.

**CAUTION:** The item is heavy, assembly should be performed by two people.



STEP 3.

